



INSTRUCTIONS

EN – STEAM DOES NOT DETECT WHEEL BASE

1.

- *Open the Steam application*
- *Select „View“*
- *Select „Settings“*
- *Select „Controller“*
- *In General Controller Settings, uncheck the checkbox for „Generic Game Pad Configuration Support“.*



- *Once you have performed the steps listed above, open a STEAM racing game again, and verify the proper functionality of your device(s).*
- *If the issues persists, reinstall the STEAM client, and try it again.*

NOTES:



DE – STEAM ERKENNT DIE WHEEL BASE NICHT

1.

- Öffnen Sie die STEAM-Anwendung
- Wählen Sie „Ansicht“
- Wählen Sie „Einstellungen“
- Wählen Sie „Steuerung“
- Deaktivieren Sie unter Allgemeine Controller-Einstellungen das Kontrollkästchen für „Generic Game Pad Configuration“.



- Wenn Sie die oben genannten Schritte durchgeführt haben, öffnen Sie erneut ein STEAM-Rennspiel und überprüfen Sie die ordnungsgemäße Funktion Ihres Geräts.
- Wenn das Problem weiterhin besteht, installieren Sie den STEAM-Client neu und versuchen Sie es erneut.

